
ASSEMBLY INSTRUCTION

W2325P163375 W2325P183182 W2325P183181 W2325P195865



Return & Warranty policy:

-We strive to offer the highest quality products, and we also try our best to satisfy each and every customer that orders from us with replacement parts/or service as needed.

-1.If the items is damaged or defective, please take photos as

evidence for replacements and refunds.

-Please do not return to store, contact the seller if yon have any troubles with this product.

-2.As the cushions are all vacuum compressed, there will be some wrinkles.

Please give your cushions up to 72 hours to reach its original size and the wrinkles will basically disappear.

-3.Please do not open the compressed packages until your sofa frame is completely assembled.

ASSEMBLY INSTRUCTION


HARDWARE LIST				
NO	DESCRIPTION	SKETCH	QTY	
1	PLASTIC GASKET		4 PCS	
2	SCREWS M 8*60MM		4 PCS	
3	GASKET	0	4 PCS	
4	ALLEN KEY	<	1 PC	


PARTS LIST				
NO	DESCRIPTION	SKETCH	QTY	
A	LEG		4PCS	
В	BACK CUSHION		2PCS	
С	SEAT FRAME		1PC	
D	ARM		2PCS	
E	SEAT		1PC	
F	BACK REST		1PC	
G	CUP HOLDER	Ĩ	2PCS	


DIAGRAM1

Open the carton, and take out 2pcs back cushion and 1pc seat

В	2PCS
E	1PC










DIAGRAM5 Use the zipper to connect the seat (E) and seat frame.Put in the back cushion. B E 1PC 1PC

DIAGRAM6



Install the cup holder.




DIAGRAM7

Folding cushion.

